

To use this chart, simply find your tube size at the bottom of the chart, find the colour that matches the capacity of your motor and check against the weights on the right side.

FOR ZIPS AND SIDE CHANNEL SYSTEMS

